





















BUTTON SIZE CHART

www.sunmeibutton.com

	LIGNE (L)	MILIMETERES (MM)	INCH(in)
	12	7.5	5/16
	13	8	5/16
	14	9	11/32
	15	9.5	3/8
	16	10	13/32
	17	10.5	7/16
	18	11.5	15/32
	20	12.5	1/2
	22	14	9/16
	24	15	5/8
	26	16	21/32

	LIGNE (L)	MILIMETERES (MM)	INCH(in)
	28	18	23/32
	30	19	3/4
	32	20	13/16
	34	21.5	27/32
	36	23	7/8
	38	24	15/16
	40	25	1